




Beo4 and Beolink 1000 are remote control terminals from Bang & Olufsen. Oneremote supplies interface modules that allow third party equipment to be operated via a Bang & Olufsen remote control system.



Congratulations

With the interface module from www.one-remote.dk installed inside to your B&O Beo4 remote control terminal, you can directly operate your Hitachi TV. This user guide tells you how.

Operating with Beo4

Beo4 does not have as many keys as the TV's original remote control. Thus certain Beo4 keys have got alternative functionality. To get to this  has to be pressed first, i.e.  followed by  on the Beo4 corresponds to the actual red button on the original remote control.







The table on the opposite side shows how special Beo4 key operations translate to operations of the original remote control.































To be able to operate the TV correctly with the Beo4 the user has to be familiar with operations with the original remote control as described in the TV's user manual.


Options

The TV can be a part of different setups i.e. with B&O products. In order to handle this, the Beo4 has to be programmed with certain options. This only has to be done in the installation phase, not during the daily use.

To set an option, simply type in a sequence of 5 special buttons, as seen in the table below.

<p>Record-list-TV-7-0: When the TV is selected with   do not send  to a B&O audiomaster.</p> <p>Record-list-TV-7-1: factory When the TV is selected with  send  to a B&O audiomaster.</p> <p>With a simple scart to RCA cable the TV sound can then be enjoyed listened to via the Audiomaster speakers.  is the same command as the former AAUX.</p>
<p>Record-list-TV-9-0: Disable conversion of commands.</p> <p>Record-list-TV-9-1: factory Enable conversion of commands.</p>

Beo4	Operation
 	Turns on the TV
	Switch to TV control
	Power on/ off
 	Enter
 *1	P+
 *1	P-
 *1	i+
 *1	Return
 	Zoom
 	Clock
	Menu
	AV
 	I-II
 	Input 1
 	Input 2
 	Input 3
 	Input 4
 	RGB 1
 	RGB 2

*1
As the direct function of the coloured function buttons has been assigned to other functions, they have to be preceeded with a  to retrieve the actual coloured function.

 	Grøn
 	Gul
 	Rød
 	Blå